STRONG & RELIABLE
RAM
"The Best Overall Value In The Industry"

10K Support / 8K Lift Capacity ¾" Hex Head Sidewind Square Tube Jack Operation Instructions

TJD-10000S-B model
w/handle attached

To use drill on this model, remove pin/clip on handle and slide handle off. That will expose the hex head to be able to operate with a drill.



Pacific Rim International, LLC
19120 SE 34th Street., Suite 105
Vancouver, WA 98683
Phone: 360-859-3828

⚠ WARNING

READ INSTRUCTIONS CAREFULLY BEFORE ATTEMPTING TO INSTALL AND OPERATE. FAILURE TO FOLLOW THESE INSTRUCTIONS AND BASIC SAFETY PRECAUTIONS MAY RESULT IN SERIOUS PERSONAL INJURY.

To install jack on a trailer see welding instructions on the RAM website.

To extended the jack move hex head clockwise. To retract the jack move hex head counter clockwise.

When operating the jack with a drill use a cordless model at low speed only and with a clutch feature. Do not use an impact wrench or other high torque devices. It could cause damage to the jack.

This jack has a 15" total travel distance. It is important to stop the drill operation when reaching the end of the travel distance on the jack. Over retracting or over extending the jack could result in damaging the gears and/or screw/nut assembly and could also cause personal injury. Any damage to the jack caused by over extension or over retraction by a power tool or hand crank will void any warranty and Pacific Trailer Products/Pacific Rim International is not held liable.

This jack is lubricated at the time it is manufactured (screw/nut assembly and gears). It is also equipped with grease zerks to lubricate the gears and screw/nut assembly. One can also lubricate the gears by removing the top cap and hand wiping in additional grease. Lubricate jack as needed with any EP2 type grease. Periodic lubrication will depend on amount of use.

Pacific Trailer Products/Pacific Rim International cannot be held liable for improper installation, use, or maintenance of this product.